

Thank you for purchasing a Matki Preference Solid Surface Shower Tray. We hope that you will be pleased with your purchase and that it will give you years of showering satisfaction.

- Prior to Installation Please check that your shower tray is as ordered and is undamaged. The pack should contain tray, shower waste and solid surface drain cover. Check that tray is level.

- Installation The Matki Preference shower tray has a flat base and must be installed on a flat level surface covering the complete tray area. Tray can be bedded on a base of weak sand and cement mix or using flexible adhesive. Check that top of tray is level on all sides.

- During Installation Please protect tray surface and clean off any paint or adhesive spills immediately and rinse area with water.

- Prior to Tiling Please carry out drainage test on the tray.

- Cleaning For everyday care clean with soap and water or household detergent. Rinse thoroughly. Marks can usually be removed using a mild abrasive cleaner such as CIF and lightly rubbing with a plastic scouring pad (do not use a metal scouring pad). Rinse thoroughly with warm water. For certain marks, white spirit or methylated spirit can be used if followed by thorough rinsing with warm water. For more serious marks, please contact Matki for a Preference Restorer Repair Kit.